Original FG Ersatz- und Tuningteile Original FG Ersatz- und Tuningteile

Klebeanleitung für/ *Instruction for* Best.-Nr./ *Item N°.* 05185/ 05185/01

Modellaufkleber für Mini Cooper/ *Decal set for Mini Cooper*



We recommend to paint the inside of the transparent polycarbonate bodyshells. This way the colour is protected and the bodyshell gets a brilliant shine.
First of all clean the inside of the body either with spirit or some water and soap liquid, then dry it carefully with a clean cloth.
If you want to have transparent windows you have to stick an adhesive foil on the corresponding window areas from the inside before colouring. Apply several thin lacquer coatings inside but make sure every single coating dries well before you spray on the next. After the applied lacquer is dry you can remove the adhesive foil inside and the body protective foil outside and fix the stickers as shown on the pictures.

FG Modellsport GmbH
Spanningerstr. 2
73650 Winterbach-Germany
Phone: +49 7181 9677-0
Fax: +49 7181 9677-20
info@fg-modellsport.de
www.fg-modellsport.de

Abbildungen zeigen Teile, die nicht im Lieferumfang enthalten sind.
Pictures show parts which are not included in the delivery.

Bei durchsichtigen Polycarbonat-Karosserien empfehlen wir die Innenseite der Karosserie zu lackieren. Die Farbe wird dadurch geschützt und die Karosserie bekommt von außen einen Glanz.

Vor dem Lackieren die Karosserie-Innenseite mit Spiritus oder mit etwas Wasser und Seifenlösung reinigen und mit einem sauberen Tuch abtrocknen. Sollen die Scheiben durchsichtig bleiben, Scheibenflächen auf der Innenseite vor dem Lackieren mit einer Klebefolie abkleben. Mehrere dünne Lackschichten auf die Innenseite der Karosserie auftragen. Jede Lackschicht gut abtrocknen lassen, bevor neu aufgesprüht wird.

Aufgesprühten Lack gut abtrocknen lassen, danach die Klebefolie innen und die Karosserie-Schutzfolie außen abziehen. Modellaufkleber nach Abbildung aufkleben.